

Waterproofing System for Flat Roofs & Balconies ETAG 005

Expected life time:
W2-10 years
W3-25 years

Resistance to Mechanical Damage:
P1-low/P4-high

Application Steps:

1) Surface Preparation & Joint-crack Repair

- The surface needs to be clean, dry and sound, free of any contamination which may harmfully affect the adhesion of the membrane
- For joints & cracks applied locally Mariflex®PU30-PU40 by application gun

2) Primer

- Apply primer to ensure max adhesion to the surface Mariseal® 710/Mariseal® Aqua Primer
- Consumption: ~0,2-0,4kg/m²

3) Waterproofing Membrane

- Mariseal® 250 applied by roller in 2-4 layers Between the 1st & 2nd layers reinforced with Mariseal® Fabric
- Consumption: for W2: ~2,0-2,5kg/m²
for W3: ~3,5-4,1kg/m²

Water Vapor Permeability



Heat and Frost Resistant



UV Resistant



High Pedestrian Traffic



1. Surface Preparation & Joint-crack Repair
2. Mariseal® 710/ Mariseal® Aqua Primer
3. Mariseal® 250
4. Mariseal® Fabric/Mariseal® 250



Tips:

Primer & membrane should be applied by short haired mohair roller!

