

Varnishes for Stamped Concrete

Resistance to Mechanical Damage: P1-low/P4-high

Application Steps:

1) Surface Preparation & Joint-crack Repair

- The surface needs to be clean, dry and sound, free of any contamination which may harmfully affect the adhesion of the membrane
- For joints & cracks applied locally Mariflex® PU30-PU40 by application gun

2) Primer

- Apply primer for stamped concrete Maripur® 7400W
- Consumption: ~0,15kg/m² in one or two layers

3) Varnishes

- Apply the protective polyurethane varnish for stamped concrete Maripur® 7500 glossy/Maripur® 7600 matt
- Consumption: ~0,15kg/m² in one or two layers

Standard Performance **STANDARD**

UV Resistant



Hight Pedestrian Traffic



Water Vapor Permeability



Spray Application



1. Surface Preparation & Joint-crack Repair
2. Maripur® 7400W
3. Maripur® 7500/Maripur® 7600



Tips:

1. Polyurethane varnishes with high resistance to impact and abrasion!

2. Stability to UV exposure!