

### Application Steps:

#### 1) Surface Preparation & Joint-crack Repair

- The surface needs to be clean, dry and sound, free of any contamination which may harmfully affect the adhesion of the membrane
- For joints & cracks applied locally Mariflex®PU30-PU40 by application gun

#### 2) Primer

- Apply primer to ensure max adhesion to the surface Mariseal® 750
- Consumption: ~0,2-0,3kg/m<sup>2</sup> in one layer

#### 3) Waterproofing Membrane

- Mariseal® 300 applied by roller in 2-3 layers Between the 1st & 2nd layers reinforce the whole surface with Mariseal® Fabric

- Consumption: ~1,5-2,5kg/m<sup>2</sup>

Solvent Free




NSF Certified for Drinking Water



Odor Free



Heat & Frost Resistant



1. Surface Preparation & Joint-crack Repair
2. Mariseal® 750
3. Mariseal® 300
4. Mariseal® Fabric/Mariseal® 300



1. Mariseal® 300 available in blue & grey colour!

### Tips:

2. Primer & membrane should be applied by short haired mohair roller!